

Installation of Jim's Diode kit

Remove the left side front black plastic frame cover.

Locate the wire bundle coming from the dash

If you don't want to tap in at this point,

You can remove the tank and

tap into the wires under the tank.

Locate the Light Green and Black wires in the
Wire bundle.

Locate the Black with white tracer wire in the same bundle.

Connect the Diode kit per the drawing below..

